# Multi Degrees of Freedom Systems

Giacomo Boffi

Dipartimento di Ingegneria Civile e Ambientale, Politecnico di Milano

April 23, 2015

### MultiDOF Systems

Giacomo Boffi

Introductory

The Homogeneous

Modal Analysis

Examples

# Outline

Introductory Remarks

An Example

The Equation of Motion, a System of Linear

Differential Equations

Matrices are Linear Operators

Properties of Structural Matrices

An example

The Homogeneous Problem

The Homogeneous Equation of Motion

Eigenvalues and Eigenvectors

Eigenvectors are Orthogonal

Modal Analysis

Eigenvectors are a base

EoM in Modal Coordinates


**Initial Conditions** 

Examples

2 DOF System

# Introductory Remarks

Consider an undamped system with two masses and two degrees of freedom.



We can separate the two masses, single out the spring forces and, using the D'Alembert Principle, the inertial forces and, finally, write an equation of dynamic equilibrium for each mass.

$$k_{1}x_{1} - k_{2}(x_{1} - x_{2})$$

$$m_{1}\ddot{x}_{1} + (k_{1} + k_{2})x_{1} - k_{2}x_{2} = p_{1}(t)$$

$$k_{2}(x_{2} - x_{1}) - p_{2} - k_{3}x_{2}$$

$$m_{2}\ddot{x}_{2} - k_{2}x_{1} + (k_{2} + k_{3})x_{2} = p_{2}(t)$$

### MultiDOF Systems

Giacomo Boffi

ntroductory

Remarks

The Equation of Motio Matrices are Linear Operators

Properties of Structural Matrices

The Homogeneous Problem

Modal Analysis

Example

# The equation of motion of a 2DOF system

With some little rearrangement we have a system of two linear differential equations in two variables,  $x_1(t)$  and  $x_2(t)$ :

$$\begin{cases} m_1\ddot{x}_1 + (k_1 + k_2)x_1 - k_2x_2 = p_1(t), \\ m_2\ddot{x}_2 - k_2x_1 + (k_2 + k_3)x_2 = p_2(t). \end{cases}$$

### MultiDOF Systems

Giacomo Boffi

Introductory

The Homogeneo

Modal Analysi

xamples

MultiDOF Systems

Giacomo Boffi

Introductory Remarks

The Equation of Motion

perators

Properties of Structura Matrices

The Homogeneous

Modal Analysis

Examples

# The equation of motion of a 2DOF system

Introducing the loading vector  $\mathbf{p}$ , the vector of inertial forces  $\mathbf{f}_I$  and the vector of elastic forces  $\mathbf{f}_S$ ,

$$\mathbf{p} = \begin{Bmatrix} p_1(t) \\ p_2(t) \end{Bmatrix}, \quad \mathbf{f}_I = \begin{Bmatrix} f_{I,1} \\ f_{I,2} \end{Bmatrix}, \quad \mathbf{f}_S = \begin{Bmatrix} f_{S,1} \\ f_{S,2} \end{Bmatrix}$$

we can write a vectorial equation of equilibrium:

$$\mathbf{f_l} + \mathbf{f_S} = \mathbf{p}(t).$$

### MultiDOF Systems

Giacomo Boffi

Introductory

An Evamula

The Equation of Motion

Operators

Matrices

The Homogeneous

Modal Analysis

Examples

$$f_S = Kx$$

It is possible to write the linear relationship between  $\mathbf{f}_S$  and the vector of displacements  $\mathbf{x} = \left\{x_1x_2\right\}^T$  in terms of a matrix product.

In our example it is

$$\mathbf{f}_{S} = \begin{bmatrix} k_1 + k_2 & -k_2 \\ -k_2 & k_2 + k_3 \end{bmatrix} \mathbf{x} = \mathbf{K} \mathbf{x}$$

introducing the stiffness matrix **K**.

The stiffness matrix **K** has a number of rows equal to the number of elastic forces, i.e., one force for each *DOF* and a number of columns equal to the number of the *DOF*.

The stiffness matrix  $\mathbf{K}$  is hence a square matrix  $\mathbf{k}$   $\mathbf{k}$ 

MultiDOF Systems

Giacomo Boffi

Introductory

An Example
The Equation of Motion

Matrices are Linear Operators Properties of Structural

Matrices
An example

The Homogeneous

Modal Analysis

Evamples

# $f_I = M\ddot{x}$

Analogously, introducing the mass matrix  $\mathbf{M}$  that, for our example, is

$$\mathbf{M} = \begin{bmatrix} m_1 & 0 \\ 0 & m_2 \end{bmatrix}$$

we can write

$$\mathbf{f}_{I} = \mathbf{M} \ddot{\mathbf{x}}.$$

Also the mass matrix  $\mathbf{M}$  is a square matrix, with number of rows and columns equal to the number of DOF's.

### MultiDOF Systems

Giacomo Boffi

Introductory Remarks

An Example
The Equation of Motion
Matrices are Linear

Properties of Structural Matrices

The Homogeneous Problem

Modal Analysis

Examples

# Matrix Equation

Finally it is possible to write the equation of motion in matrix format:

$$\mathbf{M}\ddot{\mathbf{x}} + \mathbf{K}\mathbf{x} = \mathbf{p}(t).$$

Of course, we can consider the damping forces too, taking into account the velocity vector  $\dot{\mathbf{x}}$ , introducing a damping matrix  $\mathbf{C}$  and writing

$$\mathbf{M}\ddot{\mathbf{x}} + \mathbf{C}\dot{\mathbf{x}} + \mathbf{K}\mathbf{x} = \mathbf{p}(t),$$

however it is now more productive to keep our attention on undamped systems.

### MultiDOF Systems

Giacomo Boffi

Introductory Remarks

An Example
The Equation of Motion
Matrices are Linear

Properties of Structural Matrices

The Homogeneou

Modal Analysis

.

# Properties of **K**

- ▶ **K** is symmetrical, because the elastic force that acts on mass i due to an unit displacement of mass j,  $f_{S,i} = k_{ij}$  is equal to the force on mass j due to unit diplacement of mass i,  $f_{S,j} = k_{ji}$  in virtue of Betti's theorem.
- ► The strain energy *V* for a discrete system can be written

$$V = \frac{1}{2} \mathbf{x}^T \mathbf{f}_S = \frac{1}{2} \mathbf{x}^T \mathbf{K} \mathbf{x},$$

because the strain energy is positive it follows that  ${\bf K}$  is a positive definite matrix.

### MultiDOF Systems

Giacomo Boffi

Introductory

mtrouuctory Remarks

The Equation of Motion

Properties of Structural

An examp

The Homogeneous Problem

Modal Analysis

Examples

# Properties of **M**

Restricting our discussion to systems whose degrees of freedom are the displacements of a set of discrete masses, we have that the mass matrix is a diagonal matrix, with all its diagonal elements greater than zero. Such a matrix is symmetrical and definite positive, as well as the stiffness matrix is symmetrical and definite positive.

En passant, take note that the kinetic energy for a discrete system is

$$T = \frac{1}{2} \dot{\mathbf{x}}^T \mathbf{M} \, \dot{\mathbf{x}}.$$

### MultiDOF Systems

Giacomo Boffi

Introductory

An Example

Operators
Properties of Structural

An example

The Homogeneo

Modal Analysis

Ĭ

# Generalisation of previous results

The findings in the previous two slides can be generalised to the *structural matrices* of generic structural systems, with one exception.

For a general structural system, **M** could be *semi-definite* positive, that is for some particular displacement vector the kinetic energy could be zero.

### MultiDOF Systems

Giacomo Boffi

Introductory Remarks

Remarks

The Equation of Motion

Matrices are Linear

Properties of Structural Matrices


The Homogeneous

Modal Analysis

Examples

# The problem

Graphical statement of the problem



 $k_1 = 2k$ ,  $k_2 = k$ ;  $m_1 = 2m$ ,  $m_2 = m$ ;  $p(t) = p_0 \sin \omega t$ .

The equations of motion

$$m_1\ddot{x}_1 + k_1x_1 + k_2(x_1 - x_2) = p_0 \sin \omega t,$$
  
 $m_2\ddot{x}_2 + k_2(x_2 - x_1) = 0.$ 

... but we prefer the matrix notation ...

## MultiDOF Systems

Giacomo Boffi

Introductory Remarks

An Example
The Equation of Motion

Operators
Properties of Structural

An example

The Homogeneous

Modal Analysis

Examples

# The steady state solution

because using the matrix notation we can follow the same steps we used to find the steady-state response of a SDOF system. First, the equation of motion

$$m\begin{bmatrix} 2 & 0 \\ 0 & 1 \end{bmatrix} \ddot{\mathbf{x}} + k \begin{bmatrix} 3 & -1 \\ -1 & 1 \end{bmatrix} \mathbf{x} = p_0 \begin{Bmatrix} 1 \\ 0 \end{Bmatrix} \sin \omega t$$

substituting  $\mathbf{x}(t) = \boldsymbol{\xi} \sin \omega t$  and simplifying  $\sin \omega t$ , dividing by k, with  $\omega_0^2 = k/m$ ,  $\beta^2 = \omega^2/\omega_0^2$  and  $\Delta_{\rm st} = p_0/k$  the above equation can be written

$$\left(\begin{bmatrix}3 & -1\\ -1 & 1\end{bmatrix} - \beta^2 \begin{bmatrix}2 & 0\\ 0 & 1\end{bmatrix}\right) \boldsymbol{\xi} = \begin{bmatrix}3 - 2\beta^2 & -1\\ -1 & 1 - \beta^2\end{bmatrix} \boldsymbol{\xi} = \Delta_{st} \begin{Bmatrix}1\\ 0\end{Bmatrix}$$

solving for  $\boldsymbol{\xi}/\Delta_{\rm st}$  gives

$$\frac{\boldsymbol{\xi}}{\Delta_{\rm st}} = \frac{\begin{bmatrix} 1 - \beta^2 & 1 \\ 1 & 3 - 2\beta^2 \end{bmatrix} \begin{Bmatrix} 1 \\ 0 \end{Bmatrix}}{2\beta^4 - 5\beta^2 + 2} = \frac{\begin{Bmatrix} 1 - \beta^2 \\ 1 \end{Bmatrix}}{(2\beta^2 - 1)(\beta^2 - 2)}.$$

### MultiDOF Systems

Giacomo Boffi

Introductory

Remarks

The Equation of Motion

Operators

An example


The Homogeneous Problem

Modal Analysis

Examples

# The solution, graphically

Steady-State Response for a 2 DOF System, Harmonic Load



### MultiDOF Systems

Giacomo Boffi

Introductory

An Example
The Equation of Mo

Operators

Properties of Structural

An example

The Homogeneou

Modal Analysis

Examples

# Homogeneous equation of motion

To understand the behaviour of a *MDOF* system, we start writing *the homogeneous equation of motion*,

$$\mathbf{M}\ddot{\mathbf{x}} + \mathbf{K}\mathbf{x} = \mathbf{0}.$$

The solution, in analogy with the SDOF case, can be written in terms of a harmonic function of unknown frequency and, using the concept of separation of variables, of a constant vector, the so called  $shape\ vector\ \psi$ :

$$\mathbf{x}(t) = \boldsymbol{\psi}(A\sin\omega t + B\cos\omega t).$$

Substituting in the equation of free vibrations, we have

$$(\mathbf{K} - \omega^2 \mathbf{M}) \, \boldsymbol{\psi}(A \sin \omega t + B \cos \omega t) = \mathbf{0}$$

### MultiDOF Systems

Giacomo Boffi

Introductory Remarks

The Homogeneous Problem

The Homogeneous Equation of Motion

igenvalues and igenvectors igenvectors are

Modal Analysis

Examples

# Eigenvalues

The previous equation must hold for every value of t, so it can be simplified removing the time dependency:

$$\left(\mathbf{K} - \omega^2 \mathbf{M}\right) \boldsymbol{\psi} = \mathbf{0}.$$

This is a homogeneous linear equation, with unknowns  $\psi_i$  and the coefficients that depends on the parameter  $\omega^2$ . Speaking of homogeneous systems, we know that there is always a trivial solution,  $\psi = 0$ , and that different non-zero solutions are available when the determinant of the matrix of coefficients is equal to zero,

$$\det\left(\mathbf{K}-\omega^{2}\mathbf{M}\right)=0$$

The eigenvalues of the MDOF system are the values of  $\omega^2$  for which the above equation (the equation of frequencies) is verified.

### MultiDOF Systems

Giacomo Boffi

Introductory

The Homogeneous

The Homogeneous Equation of Motion

Eigenvalues and Eigenvectors Eigenvectors are

Modal Analysis

--vamnles

# Eigenvalues, cont.

For a system with N degrees of freedom the expansion of  $\det \left( \mathbf{K} - \omega^2 \mathbf{M} \right)$  is an algebraic polynomial of degree N in  $\omega^2$ .

A polynomial of degree N has in general N real or complex conjugate roots.

When the matrices involved are symmetric, as it is always the case for structural matrices, the roots,  $\omega_i^2$ ,  $i=1,\ldots,N$  are all real.

If both K and M are positive definite matrices, condition that is always satisfied by stable structural systems, the roots (the eigenvalues) are also positive,

$$\omega_i^2 > 0$$
 for  $i = 1, \ldots, N$ .

### MultiDOF Systems

Giacomo Boffi

Introductory Remarks

The Homogeneous

The Homogeneous

Eigenvalues and

Eigenvectors are

Modal Analysis

Example

# Eigenvectors

Substituting one of the N roots  $\omega_i^2$  in the characteristic equation,

$$\left(\mathbf{K} - \omega_i^2 \mathbf{M}\right) \boldsymbol{\psi}_i = \mathbf{0}$$

the resulting system of N-1 linearly independent equations can be solved (except for a scale factor) for  $\psi_i$ , the eigenvector corresponding to the eigenvalue  $\omega_i^2$ .

A common choice for the normalisation of the eigenvectors is normalisation with respect to the mass matrix,  $\boldsymbol{\psi}_i^T \mathbf{M} \, \boldsymbol{\psi}_i = 1$ 

Please consider that substituting different values for  $\omega_i^2$  in the characteristic equation you obtain different linear systems, with different  $\psi$  solutions.

### MultiDOF Systems

Giacomo Boffi

Introductory

The Homogeneo

Equation of Motion

Eigenvalues and Eigenvectors

Orthogonal

Evamples

# **Initial Conditions**

The most general expression (the general integral) for the displacement of a homogeneous system is

$$\mathbf{x}(t) = \sum_{i=1}^{N} \boldsymbol{\psi}_{i}(A_{i} \sin \omega_{i} t + B_{i} \cos \omega_{i} t).$$

In the general integral there are 2N unknown *constants of integration*, that must be determined in terms of the initial conditions.

### MultiDOF Systems

Giacomo Boffi

Introductory Remarks

The Homogeneous Problem

> ne Homogeneous uation of Motion

Eigenvectors are Orthogonal

Modal Analysis

Examples

# **Initial Conditions**

Usually the initial conditions are expressed in terms of initial displacements and initial velocities  $\mathbf{x}_0$  and  $\dot{\mathbf{x}}_0$ , so we start deriving the expression of displacement with respect to time to obtain

$$\dot{\mathbf{x}}(t) = \sum_{i=1}^{N} \boldsymbol{\psi}_{i} \omega_{i} (A_{i} \cos \omega_{i} t - B_{i} \sin \omega_{i} t)$$

and evaluating the displacement and velocity for t=0 it is

$$\mathbf{x}(0) = \sum_{i=1}^{N} \boldsymbol{\psi}_i B_i = \mathbf{x}_0, \qquad \dot{\mathbf{x}}(0) = \sum_{i=1}^{N} \boldsymbol{\psi}_i \omega_i A_i = \dot{\mathbf{x}}_0.$$

The above equations are vector equations, each one corresponding to a system of N equations, so we can compute the 2N constants of integration solving the 2N equations

$$\sum_{i=1}^{N} \psi_{ji} B_{i} = x_{0,j}, \qquad \sum_{i=1}^{N} \psi_{ji} \omega_{i} A_{i} = \dot{x}_{0,j}, \qquad j = 1, \ldots, N.$$

### MultiDOF Systems

Giacomo Boffi

Introductory

The Homogeneous

The Homogeneous Equation of Motion

Eigenvalues and Eigenvectors Eigenvectors are Orthogonal

Modal Analysis

kamples

# Orthogonality - 1

Take into consideration two distinct eigenvalues,  $\omega_r^2$  and  $\omega_s^2$ , and write the characteristic equation for each eigenvalue:

$$\mathbf{K}\,\boldsymbol{\psi}_r = \omega_r^2 \mathbf{M}\,\boldsymbol{\psi}_r$$
$$\mathbf{K}\,\boldsymbol{\psi}_s = \omega_s^2 \mathbf{M}\,\boldsymbol{\psi}_s$$

premultiply each equation member by the transpose of the *other* eigenvector

$$\psi_s^{\mathsf{T}} \mathbf{K} \, \psi_r = \omega_r^2 \psi_s^{\mathsf{T}} \mathbf{M} \, \psi_r$$
$$\psi_r^{\mathsf{T}} \mathbf{K} \, \psi_s = \omega_s^2 \psi_r^{\mathsf{T}} \mathbf{M} \, \psi_s$$

### MultiDOF Systems

Giacomo Boffi

Introductory Remarks

The Homogeneous

roblem The Homogeneous

Eigenvalues and Eigenvectors

Modal Analysis

Examples

# Orthogonality - 2

The term  $\boldsymbol{\psi}_s^T \mathbf{K} \boldsymbol{\psi}_r$  is a scalar, hence

$$oldsymbol{\psi}_{s}^{ op} \mathbf{K} \, oldsymbol{\psi}_{r} = oldsymbol{(\psi}_{s}^{ op} \mathbf{K} \, oldsymbol{\psi}_{r})^{ op} = oldsymbol{\psi}_{r}^{ op} \mathbf{K}^{ op} \, oldsymbol{\psi}_{s}$$

but **K** is symmetrical,  $\mathbf{K}^T = \mathbf{K}$  and we have

$$\boldsymbol{\psi}_{s}^{\mathsf{T}} \mathbf{K} \, \boldsymbol{\psi}_{r} = \boldsymbol{\psi}_{r}^{\mathsf{T}} \mathbf{K} \, \boldsymbol{\psi}_{s}.$$

By a similar derivation

$$\boldsymbol{\psi}_{s}^{T} \mathbf{M} \, \boldsymbol{\psi}_{r} = \boldsymbol{\psi}_{r}^{T} \mathbf{M} \, \boldsymbol{\psi}_{s}$$

### MultiDOF Systems

Giacomo Boffi

Introductory

The Hamagana

The Homogeneous Problem

Equation of Motion

Eigenvectors

Eigenvectors are
Orthogonal

Modal Analysi

Examples

# Orthogonality - 3

Substituting our last identities in the previous equations, we have

$$\boldsymbol{\psi}_r^{\mathsf{T}} \mathbf{K} \, \boldsymbol{\psi}_s = \omega_r^2 \boldsymbol{\psi}_r^{\mathsf{T}} \mathbf{M} \, \boldsymbol{\psi}_s$$
  
 $\boldsymbol{\psi}_r^{\mathsf{T}} \mathbf{K} \, \boldsymbol{\psi}_s = \omega_s^2 \boldsymbol{\psi}_r^{\mathsf{T}} \mathbf{M} \, \boldsymbol{\psi}_s$ 

subtracting member by member we find that

$$(\omega_r^2 - \omega_s^2) \boldsymbol{\psi}_r^T \mathbf{M} \boldsymbol{\psi}_s = 0$$

We started with the hypothesis that  $\omega_r^2 \neq \omega_s^2$ , so for every  $r \neq s$  we have that the corresponding eigenvectors are orthogonal with respect to the mass matrix

$$\boldsymbol{\psi}_r^T \mathbf{M} \, \boldsymbol{\psi}_s = 0, \quad \text{for } r \neq s.$$

### MultiDOF Systems

Giacomo Boffi

Introductory Remarks

The Homogeneous

The Homogeneous
Equation of Motion
Eigenvalues and

Eigenvectors are Orthogonal

Modal Analysis

# Orthogonality - 4

The eigenvectors are orthogonal also with respect to the stiffness matrix:

$$\boldsymbol{\psi}_{s}^{\mathsf{T}}\mathbf{K}\,\boldsymbol{\psi}_{r}=\omega_{r}^{2}\boldsymbol{\psi}_{s}^{\mathsf{T}}\mathbf{M}\,\boldsymbol{\psi}_{r}=0,\quad\text{for }r\neq s.$$

By definition

$$M_i = \boldsymbol{\psi}_i^T \mathbf{M} \, \boldsymbol{\psi}_i$$

and

$$\boldsymbol{\psi}_{i}^{T}\mathbf{K}\,\boldsymbol{\psi}_{i}=\omega_{i}^{2}M_{i}.$$

### MultiDOF Systems

Giacomo Boffi

Introductory

The Homogeneous Problem

Equation of Motion Eigenvalues and Eigenvectors Eigenvectors are

Modal Analysis

xamples

# Eigenvectors are a base

The eigenvectors are linearly independent, so for every vector  $\mathbf{x}$  we can write

$$\mathbf{x} = \sum_{j=1}^{N} \boldsymbol{\psi}_{j} q_{j}.$$

The coefficients are readily given by premultiplication of  $\mathbf{x}$  by  $\boldsymbol{\psi}_i^T \mathbf{M}$ , because

$$\boldsymbol{\psi}_i^T \mathbf{M} \mathbf{x} = \sum_{j=1}^N \boldsymbol{\psi}_i^T \mathbf{M} \, \boldsymbol{\psi}_j q_j = \boldsymbol{\psi}_i^T \mathbf{M} \, \boldsymbol{\psi}_i q_i = M_i q_i$$

in virtue of the ortogonality of the eigenvectors with respect to the mass matrix, and the above relationship gives

$$q_j = \frac{\boldsymbol{\psi}_j^T \mathbf{M} \mathbf{x}}{M_j}.$$

### MultiDOF Systems

Giacomo Boffi

Introductory Remarks

The Homogeneous Problem

Modal Analysis

EoM in Modal Coordinates

Examples

# Eigenvectors are a base

Generalising our results for the displacement vector to the acceleration vector, we can write

$$\mathbf{x}(t) = \sum_{j=1}^{N} \boldsymbol{\psi}_j q_j(t), \qquad \qquad \ddot{\mathbf{x}}(t) = \sum_{j=1}^{N} \boldsymbol{\psi}_j \ddot{q}_j(t), \ x_i(t) = \sum_{j=1}^{N} \Psi_{ij} q_j(t), \qquad \qquad \ddot{x}_i(t) = \sum_{j=1}^{N} \psi_{ij} \ddot{q}_j(t).$$

Introducing  $\mathbf{q}(t)$ , the vector of *modal coordinates* and  $\mathbf{\Psi}$ , the *eigenvector matrix*, whose columns are the eigenvectors,

$$\mathbf{x}(t) = \mathbf{\Psi} \, \mathbf{q}(t), \qquad \qquad \ddot{\mathbf{x}}(t) = \mathbf{\Psi} \, \ddot{\mathbf{q}}(t).$$

### MultiDOF Systems

Giacomo Boffi

Introductory

The Homogeneous

Modal Analysis

Eigenvectors are a base EoM in Modal Coordinate Initial Conditions

Examples

# EoM in Modal Coordinates...

Substituting the last two equations in the equation of motion,

$$\mathbf{M} \mathbf{\Psi} \ddot{\mathbf{a}} + \mathbf{K} \mathbf{\Psi} \mathbf{a} = \mathbf{p}(t)$$

premultiplying by  $\Psi^T$ 

$$\mathbf{\Psi}^{T}\mathbf{M}\,\mathbf{\Psi}\,\ddot{\mathbf{q}} + \mathbf{\Psi}^{T}\mathbf{K}\,\mathbf{\Psi}\,\mathbf{q} = \mathbf{\Psi}^{T}\mathbf{p}(t)$$

introducing the so called *starred* matrices we can finally write

$$\mathbf{M}^{\star}\ddot{\mathbf{q}} + \mathbf{K}^{\star}\mathbf{q} = \mathbf{p}^{\star}(t)$$

where  $\mathbf{p}^{\star}(t) = \mathbf{\Psi}^{T}\mathbf{p}(t)$ , and the scalar equation are

$$p_i^{\star} = \sum m_{ij}^{\star} \ddot{q}_j + \sum k_{ij}^{\star} q_j.$$

### MultiDOF Systems

Giacomo Boffi

Introductory Remarks

The Homogeneous Problem

Modal Analysis

Eigenvectors are a base
EoM in Modal Coordinates

Examples

# ... are N independent equations!

We must examine the structure of the starred symbols. The generic element, with indexes i and j, of the *starred* matrices can be expressed in terms of single eigenvectors,

$$m_{ij}^{\star} = \boldsymbol{\psi}_{i}^{\mathsf{T}} \mathbf{M} \, \boldsymbol{\psi}_{j} \qquad \qquad = \delta_{ij} M_{i},$$
  
 $k_{ij}^{\star} = \boldsymbol{\psi}_{i}^{\mathsf{T}} \mathbf{K} \, \boldsymbol{\psi}_{j} \qquad \qquad = \omega_{i}^{2} \delta_{ij} M_{i}.$ 

where  $\delta_{ii}$  is the Kroneker symbol,

$$\delta_{ij} = \begin{cases} 1 & i = j \\ 0 & i \neq j \end{cases}$$

Substituting in the equation of motion, with  $p_i^* = \boldsymbol{\psi}_i^T \mathbf{p}(t)$  we have a set of uncoupled equations

$$M_i\ddot{q}_i + \omega_i^2 M_i q_i = p_i^{\star}(t), \qquad i = 1, \dots, N$$

### MultiDOF Systems

Giacomo Boffi

Introductory Remarks

The Homogeneous Problem

Modal Analysis
Eigenvectors are a base
EoM in Modal Coordinate

Evamples

# Initial Conditions Revisited

The initial displacements can be written in modal coordinates,

$$\mathbf{x}_0 = \mathbf{\Psi} \, \mathbf{q}_0$$

and premultiplying both members by  $\Psi^T \mathbf{M}$  we have the following relationship:

$$\mathbf{\Psi}^{T}\mathbf{M}\,\mathbf{x}_{0} = \mathbf{\Psi}^{T}\mathbf{M}\,\mathbf{\Psi}\,\mathbf{q}_{0} = \mathbf{M}^{\star}\mathbf{q}_{0}.$$

Premultiplying by the inverse of  $\mathbf{M}^*$  and taking into account that  $\mathbf{M}^*$  is diagonal,

$$\mathbf{q}_0 = (\mathbf{M}^{\star})^{-1} \, \mathbf{\Psi}^T \mathbf{M} \, \mathbf{x}_0 \quad \Rightarrow \quad q_{i0} = \frac{\mathbf{\psi}_i^T \mathbf{M} \, \mathbf{x}_0}{M_i}$$

and, analogously,

$$\dot{q}_{i0} = rac{oldsymbol{\psi}_i^{\ T} \mathbf{M} \, \dot{\mathbf{x}}_0}{M_i}$$

### MultiDOF Systems

Giacomo Boffi

Introductory

The Homogeneous Problem

Modal Analysis

Eigenvectors are a base
EoM in Modal Coordinates

Example

# 2 DOF System

# 

$$\mathbf{x} = \begin{Bmatrix} x_1 \\ x_2 \end{Bmatrix}$$
,  $\mathbf{p}(t) = \begin{Bmatrix} 0 \\ p_0 \end{Bmatrix} \sin \omega t$ ,

 $p(t) = p_0 \sin \omega t$ .

$$\mathbf{M} = m \begin{bmatrix} 2 & 0 \\ 0 & 1 \end{bmatrix}, \ \mathbf{K} = k \begin{bmatrix} 3 & -2 \\ -2 & 2 \end{bmatrix}.$$

MultiDOF Systems

Giacomo Boffi

Introductory

The Homogeneou

Modal Analysi

Examples 2 DOF System

# Equation of frequencies

The equation of frequencies is

$$\|\mathbf{K} - \omega^2 \mathbf{M}\| = \begin{pmatrix} 3k - 2\omega^2 m & -2k \\ -2k & 2k - \omega^2 m \end{pmatrix} = 0.$$

Developing the determinant

$$(2m^2)\omega^4 - (7mk)\omega^2 + (2k^2)\omega^0 = 0, \tag{1}$$

with  $\omega_0^2 = k/m$  and  $\omega^2 = \Lambda \omega_0^2$ ,

$$2\Lambda^2 - 7\Lambda + 2 = 0 \quad \Rightarrow \quad \Lambda = \frac{7 \mp \sqrt{33}}{4}.$$
 (2)

Solving the algebraic equation in  $\omega^2$ 

$$\omega_1^2 = \frac{k}{m} \frac{7 - \sqrt{33}}{4} \qquad \qquad \omega_2^2 = \frac{k}{m} \frac{7 + \sqrt{33}}{4}$$

$$\omega_1^2 = 0.31386 \frac{k}{m} \qquad \qquad \omega_2^2 = 3.18614 \frac{k}{m}$$

### MultiDOF Systems

Giacomo Boffi

Introductory Remarks

The Homogeneous Problem

Modal Analysis

Examples
2 DOF System

# Eigenvectors

Substituting  $\omega_1^2$  for  $\omega^2$  in the first of the characteristic equations gives the ratio between the components of the first eigenvector,

$$k(3-2\times0.31386)\psi_{11}-2k\psi_{21}=0$$

while substituting  $\omega_2^2$  gives

$$k(3-2\times3.18614)\psi_{12}-2k\psi_{22}=0$$

Solving with the arbitrary assignment  $\psi_{21} = \psi_{22} = 1$  gives the *unnormalised* eigenvectors,

$$\boldsymbol{\psi}_1 = \begin{cases} +0.84307 \\ +1.00000 \end{cases}$$
,  $\boldsymbol{\psi}_2 = \begin{cases} -0.59307 \\ +1.00000 \end{cases}$ .

### MultiDOF Systems

Giacomo Boffi

Introductory Remarks

The Homogeneous

Analysis

Examples 2 DOF System

# **Normalisation**

We compute first  $M_1$  and  $M_2$ ,

$$M_{1} = \psi_{1}^{\mathsf{T}} \mathsf{M} \psi_{1}$$

$$= \left\{0.84307, \quad 1\right\} \begin{bmatrix} 2m & 0\\ 0 & m \end{bmatrix} \begin{Bmatrix} 0.84307\\ 1 \end{Bmatrix}$$

$$= \left\{1.68614m, \quad m\right\} \begin{Bmatrix} 0.84307\\ 1 \end{Bmatrix} = 2.42153m$$

$$M_2 = 1.70346m$$

the adimensional normalisation factors are

$$\alpha_1 = \sqrt{2.42153}, \qquad \alpha_2 = \sqrt{1.70346}$$

Applying the normalisation factors to the respective unnormalised eigenvectors and collecting them in a matrix, we have the *matrix of normalised eigenvectors* 

$$\Psi = \begin{bmatrix} +0.54177 & -0.45440 \\ +0.64262 & +0.76618 \end{bmatrix}$$

### MultiDOF Systems

Giacomo Boffi

Introductory

The Homogeneous

Modal Analysis

Example

oles

# Modal Loadings

The modal loading is

$$\mathbf{p}^{*}(t) = \mathbf{\Psi}^{T} \mathbf{p}(t)$$

$$= p_{0} \begin{bmatrix} +0.54177 & +0.64262 \\ -0.45440 & +0.76618 \end{bmatrix} \begin{cases} 0 \\ 1 \end{cases} \sin \omega t$$

$$= p_{0} \begin{cases} +0.64262 \\ +0.76618 \end{cases} \sin \omega t$$

### MultiDOF Systems

Giacomo Boffi

Introductory Remarks

The Homogeneous Problem

Modal Analysis

xamples

2 DOF System

# Modal EoM

Substituting its modal expansion for  $\mathbf{x}$  into the equation of motion and premultiplying by  $\mathbf{\Psi}^T$  we have the uncoupled modal equation of motion

$$\begin{cases} m\ddot{q}_1 + 0.31386k \ q_1 = +0.64262 \ p_0 \sin \omega t \\ m\ddot{q}_2 + 3.18614k \ q_2 = +0.76618 \ p_0 \sin \omega t \end{cases}$$

Note that all the terms are dimensionally correct. Dividing by m both equations, we have

$$\begin{cases} \ddot{q}_1 + \omega_1^2 q_1 = +0.64262 \frac{p_0}{m} \sin \omega t \\ \ddot{q}_2 + \omega_2^2 q_2 = +0.76618 \frac{p_0}{m} \sin \omega t \end{cases}$$

### MultiDOF Systems

Giacomo Boffi

Introductory Remarks

The Homogeneous

Modal Analysis

Examples
2 DOF System

Particular Integral

We set

$$\xi_1 = C_1 \sin \omega t$$
,  $\ddot{\xi} = -\omega^2 C_1 \sin \omega t$ 

and substitute in the first modal EoM:

$$C_1\left(\omega_1^2-\omega^2\right)\sin\omega t=\frac{p_1^{\star}}{m}\sin\omega t$$

solving for  $C_1$ 

$$C_1 = \frac{p_1^{\star}}{m} \frac{1}{\omega_1^2 - \omega^2}$$

with 
$$\omega_1^2 = K_1/m \implies m = K_1/\omega_1^2$$
:

$$C_1 = \frac{p_1^{\star}}{K_1} \frac{\omega_1^2}{\omega_1^2 - \omega^2} = \Delta_{\text{st}}^{(1)} \frac{1}{1 - \beta_1^2} \quad \text{with } \Delta_{\text{st}}^{(1)} = \frac{p_1^{\star}}{K_1} = 2.047 \frac{p_0}{k} \text{ and } \beta_1 = \frac{\omega}{\omega_1}$$

of course

$$C_2 = \Delta_{\rm st}^{(2)} \frac{1}{1 - \beta_2^2}$$
 with  $\Delta_{\rm st}^{(2)} = \frac{p_2^{\star}}{K_2} = 0.2404 \frac{p_0}{k}$  and  $\beta_2 = \frac{\omega}{\omega_2}$ 

### MultiDOF Systems

Giacomo Boffi

Introductory Remarks

The Homogeneous

Analysis

Examples
2 DOF System

# Integrals

The integrals, for our loading, are thus

$$\begin{cases} q_1(t) = A_1 \sin \omega_1 t + B_1 \cos \omega_1 t + \Delta_{\text{st}}^{(1)} \frac{\sin \omega t}{1 - \beta_1^2} \\ q_2(t) = A_2 \sin \omega_2 t + B_2 \cos \omega_2 t + \Delta_{\text{st}}^{(2)} \frac{\sin \omega t}{1 - \beta_2^2} \end{cases}$$

for a system initially at rest

$$\left\{egin{aligned} q_1(t) &= \Delta_{ ext{st}}^{(1)} rac{1}{1-eta_1^2} \left(\sin \omega t - eta_1 \sin \omega_1 t
ight) \ q_2(t) &= \Delta_{ ext{st}}^{(2)} rac{1}{1-eta_2^2} \left(\sin \omega t - eta_2 \sin \omega_2 t
ight) \end{aligned}
ight.$$

we are interested in structural degrees of freedom, too... disregarding transient

The response in structural coordinates

functions in terms of  $x_1 = \psi_{11}q_1 + \psi_{12}q_2$  and

 $x_2 = \psi_{21}q_1 + \psi_{22}q_2$ :

Using the same normalisation factors, here are the response

$$\begin{cases} x_1(t) = \left(\psi_{11} \frac{\Delta_{\text{st}}^{(1)}}{1 - \beta_1^2} + \psi_{12} \frac{\Delta_{\text{st}}^{(2)}}{1 - \beta_2^2}\right) \sin \omega t = \left(\frac{1.10926}{1 - \beta_1^2} - \frac{0.109271}{1 - \beta_2^2}\right) \frac{\rho_0}{k} \sin \omega t \\ x_2(t) = \left(\psi_{21} \frac{\Delta_{\text{st}}^{(1)}}{1 - \beta_1^2} + \psi_{22} \frac{\Delta_{\text{st}}^{(2)}}{1 - \beta_2^2}\right) \sin \omega t = \left(\frac{1.31575}{1 - \beta_1^2} + \frac{0.184245}{1 - \beta_2^2}\right) \frac{\rho_0}{k} \sin \omega t \end{cases}$$

### MultiDOF Systems

Giacomo Boffi

Introductory Remarks

The Homogeneous Problem

Modal Analysis

Examples
2 DOF System

### MultiDOF Systems


Giacomo Boffi

Introductory Remarks

The Homogeneous Problem

Modal Analysis


Examples 2 DOF System



# The response in modal coordinates

To have a feeling of the response in modal coordinates, let's say that the frequency of the load is  $\omega=2\omega_0$ .

This implies that  $\beta_1 = \frac{\omega}{\omega_1} = \frac{2.0}{\sqrt{0.31386}} = 6.37226$  and  $\beta_2 = \frac{\omega}{\omega_2} = \frac{2.0}{\sqrt{3.18614}} = 0.62771$ .



In the graph above, the responses are plotted against an adimensional time coordinate  $\alpha$  with  $\alpha = \omega_0 t$ , while the ordinates are adimensionalised with respect to  $\Delta_{\rm st} = \frac{p_0}{k}$ 

MultiDOF Systems

Giacomo Boffi

Introductory

The Homogeneous

Modal Analysi

Examples 2 DOF System