

Response by Superposition

Giacomo Boffi

Dipartimento di Ingegneria Strutturale, Politecnico di Milano

May 14, 2010

Eigenvector Expansion

For a N - DOF system, it is possible and often advantageous to represent the displacements \underline{x} in terms of a linear combination of the free vibration modal shapes, the eigenvectors, by the means of a set of modal coordinates,

$$\underline{x} = \sum \underline{\psi}_i q_i = \underline{\Psi} \underline{q}.$$

The eigenvectors play a role analogous to the role played by trigonometric functions in Fourier Analysis,

- ▶ they possess orthogonality properties,
- ▶ we will see that it is usually possible to approximate the response using only a few low frequency terms.

Inverting Eigenvector Expansion

Superposition

Giacomo Boffi

Eigenvector
Expansion

Uncoupled
Equations of
Motion

The columns of the eigenmatrix Ψ are the N linearly independent eigenvectors $\underline{\psi}_i$, hence the eigenmatrix is non-singular and it is always correct to write $\underline{q} = \Psi^{-1}\underline{x}$. However, it is not necessary to invert the eigenmatrix: take $\underline{x} = \Psi \underline{q}$, multiply by $\Psi^T \mathbf{M}$ and substitute $\mathbf{M}^* = \Psi^T \mathbf{M} \Psi$:

$$\Psi^T \mathbf{M} \underline{x} = \Psi^T \mathbf{M} \Psi \underline{q} = \mathbf{M}^* \underline{q}$$

but \mathbf{M}^* is a diagonal matrix, hence $(\mathbf{M}^*)^{-1} = \{\delta_{ij}/M_i\}$ and we can write

$$\underline{q} = \mathbf{M}^{*-1} \Psi^T \mathbf{M} \underline{x}, \quad \text{or} \quad q_i = \frac{\underline{\psi}^T \mathbf{M} \underline{x}}{M_i}$$

Note: this formula works also when we don't know all the eigenvectors and the inversion of a partial, rectangular Ψ is not feasible.

Undamped System

Superposition

Giacomo Boffi

Eigenvector
Expansion

Uncoupled
Equations of
Motion

Undamped
Damped System
Truncated Sum
Elastic Forces
Example

The displacements and accelerations are written in terms of modal coordinates, $\underline{x} = \Psi \underline{q}$, etc, all terms are premultiplied by the transpose of the eigenvectors matrix, and with $p_i^*(t) = \underline{\psi}^T \underline{p}(t)$ we can write

$$M_i \ddot{q}_i + \omega_i^2 M_i q_i = p_i^*(t), \quad i = 1, \dots, N.$$

The equations of motion written in terms of nodal coordinates constitute a system of N interdependent, *coupled* differential equations, written in terms of modal coordinates constitute a set of N independent, *uncoupled* differential equations.

Damped System

Superposition

Giacomo Boffi

Eigenvector
Expansion

Uncoupled
Equations of
Motion

Undamped

Damped System

Truncated Sum

Elastic Forces
Example

In general,

$$\mathbf{M}\ddot{\underline{\mathbf{x}}} + \mathbf{C}\dot{\underline{\mathbf{x}}} + \mathbf{K}\underline{\mathbf{x}} = \underline{\mathbf{p}}(t)$$

and with the usual stuff

$$M_i \ddot{q}_i + \underline{\boldsymbol{\psi}}^T \mathbf{C} \underline{\boldsymbol{\Psi}} \dot{\underline{\mathbf{q}}} + \omega_i^2 M_i q_i = p_i^*(t),$$

with $C_{ij} = \underline{\boldsymbol{\psi}}_i^T \mathbf{C} \underline{\boldsymbol{\psi}}_j$

$$M_i \ddot{q}_i + \sum_j C_{ij} \dot{q}_j + \omega_i^2 M_i q_i = p_i^*(t),$$

that is **the equations will be uncoupled only if $c_{ij} = \delta_{ij} C_i$** .

If we define the damping matrix as

$$\mathbf{C} = \sum_b c_b \mathbf{M} (\mathbf{M}^{-1} \mathbf{K})^b,$$

we know that, as required,

$$c_{ij} = \delta_{ij} C_i \quad \text{with } C_i (= 2\zeta_i M_i \omega_i) = \sum_b c_b (\omega_i^2)^b.$$

Damped Systems, a Comment

Superposition

Giacomo Boffi

Eigenvector
Expansion

Uncoupled
Equations of
Motion

Undamped

Damped System

Truncated Sum

Elastic Forces
Example

If the response is computed by modal superposition, it is usually preferred a simpler but equivalent procedure: for each mode of interest the analyst imposes a given damping ratio and the integration of the modal equation of equilibrium is carried out as usual.

The $\sum_b c_b \dots$ procedure is useful when, e.g. for non-linear problems, the integration of the eq. of motion is carried out in nodal coordinates, because it is easier to specify damping properties globally as elastic modes properties (that can be measured or deduced from similar outsets) than to assign correct damping properties at the *FE* level and assembling \mathbf{C} by the *FEM*.

Initial Conditions

Superposition

Giacomo Boffi

Eigenvector
Expansion

Uncoupled
Equations of
Motion

Undamped
Damped System

Truncated Sum
Elastic Forces
Example

For a damped system, the modal response can be evaluated, for rest initial conditions, using the Duhamel integral,

$$q_i(t) = \frac{1}{M_i \omega_i} \int_0^t p_i(\tau) e^{-\zeta_i \omega_i (t-\tau)} \sin \omega_{D_i} (t-\tau) d\tau$$

For different initial conditions \underline{x}_0 , $\dot{\underline{x}}_0$, we can easily have the initial conditions in modal coordinates:

$$\underline{q}_0 = \mathbf{M}^{*-1} \Psi^T \mathbf{M} \underline{x}_0$$

$$\dot{\underline{q}}_0 = \mathbf{M}^{*-1} \Psi^T \mathbf{M} \dot{\underline{x}}_0$$

and the total modal response can be obtained by superposition of Duhamel integral and free vibrations,

$$q_i(t) = e^{-\zeta_i \omega_i t} \left(q_{i,0} \cos \omega_{D_i} t + \frac{\dot{q}_{i,0} + q_{i,0} \zeta_i \omega_i}{\omega_{D_i}} \sin \omega_{D_i} t \right) + \dots$$

Truncated sum

Superposition

Giacomo Boffi

Eigenvector
Expansion

Uncoupled
Equations of
Motion

Undamped
Damped System

Truncated Sum
Elastic Forces
Example

Having computed all $q_i(t)$, we can sum all the modal responses using the eigenvectors,

$$\underline{x}(t) = \underline{\psi}_1 q_1(t) + \underline{\psi}_2 q_2(t) + \dots + \underline{\psi}_N q_N(t) = \sum_{i=1}^N \underline{\psi}_i q_i(t)$$

It is capital to understand that we can use a *truncated sum*, comprising only a few of the lower frequency modes, to obtain a good approximation of structural response:

$$\underline{x}(t) \approx \sum_{i=1}^{M < N} \underline{\psi}_i q_i(t)$$

The importance of truncated sum approximation is twofold:

- ▶ less computational effort: less eigenpairs to calculate, less equation of motion to integrate etc
- ▶ higher modes (that in common *FEM* models of building structures are rough approximations due to uncertainties in mass distribution details) potentially spurious contributions are excluded from response.

Elastic Forces

Superposition

Giacomo Boffi

Eigenvector
Expansion

Uncoupled
Equations of
Motion

Undamped
Damped System
Truncated Sum

Elastic Forces

Example

Until now, we showed interest in displacements only, but we are interested in elastic forces too. We know that elastic forces can be expressed in terms of displacements and the stiffness matrix:

$$\underline{f}_S(t) = \mathbf{K}\underline{x}(t) = \mathbf{K}\underline{\psi}_1 q_1(t) + \mathbf{K}\underline{\psi}_2 q_2(t) + \dots$$

From the characteristic equation we know that

$$\mathbf{K}\underline{\psi}_i = \omega_i^2 \mathbf{M}\underline{\psi}_i$$

substituting in the previous equation

$$\underline{f}_S(t) = \omega_1^2 \mathbf{M}\underline{\psi}_1 q_1(t) + \omega_2^2 \mathbf{M}\underline{\psi}_2 q_2(t) + \dots$$

Elastic Forces, 2

Superposition

Giacomo Boffi

Eigenvector
Expansion

Uncoupled
Equations of
Motion

Undamped
Damped System
Truncated Sum

Elastic Forces

Example

Obviously the higher modes' force contributions, e.g.


$$\underline{f}_S(t) = \omega_1^2 \mathbf{M}\underline{\psi}_1 q_1(t) + \dots + \omega_{20}^2 \mathbf{M}\underline{\psi}_{20} q_{20}(t) + \dots$$

in a truncated sum will be higher than displacement ones or, in different words, to estimate internal forces within given accuracy, a greater number of modes must be considered in a truncated sum than the number required to estimate displacements within the same accuracy

Example: problem statement

Superposition

Giacomo Boffi



$$\begin{aligned} k_1 &= 120 \text{ MN/m}, & m_1 &= 200 \text{ t}, \\ k_2 &= 240 \text{ MN/m}, & m_1 &= 300 \text{ t}, \\ k_3 &= 360 \text{ MN/m}, & m_1 &= 400 \text{ t}. \end{aligned}$$

Eigenvector
Expansion

Uncoupled
Equations of
Motion

Undamped
Damped System
Truncated Sum
Elastic Forces

Example

- The above structure is subjected to these initial conditions,

$$\begin{aligned} \underline{x}_0^T &= \{5 \text{ mm} \quad 4 \text{ mm} \quad 3 \text{ mm}\}, \\ \dot{\underline{x}}_0^T &= \{0 \quad 9 \text{ mm/s} \quad 0\}. \end{aligned}$$

Write the equation of motion using modal superposition.

- The above structure is subjected to a half-sine impulse,


$$\underline{p}^T(t) = \{1 \quad 2 \quad 2\} 2.5 \text{ MN} \sin \frac{\pi t}{t_1}, \quad \text{with } t_1 = 0.02 \text{ s}.$$

Write the equation of motion using modal superposition.

Example: structural matrices

Superposition

Giacomo Boffi



$$\begin{aligned} k_1 &= 120 \text{ MN/m}, & m_1 &= 200 \text{ t}, \\ k_2 &= 240 \text{ MN/m}, & m_1 &= 300 \text{ t}, \\ k_3 &= 360 \text{ MN/m}, & m_1 &= 400 \text{ t}. \end{aligned}$$

Eigenvector
Expansion

Uncoupled
Equations of
Motion

Undamped
Damped System
Truncated Sum
Elastic Forces

Example

The structural matrices can be written

$$\mathbf{K} = k \begin{bmatrix} 1 & -1 & 0 \\ -1 & 3 & -2 \\ 0 & -2 & 5 \end{bmatrix} = k \bar{\mathbf{K}}, \quad \text{with } k = 120 \frac{\text{MN}}{\text{m}},$$

$$\mathbf{M} = m \begin{bmatrix} 2 & 0 & 0 \\ 0 & 3 & 0 \\ 0 & 0 & 4 \end{bmatrix} = m \bar{\mathbf{M}}, \quad \text{with } m = 100000 \text{ kg}.$$

Example: adimensional eigenvalues

Superposition

Giacomo Boffi

Eigenvector
Expansion

Uncoupled
Equations of
Motion

Undamped
Damped System
Truncated Sum
Elastic Forces

Example

We want the solutions of the characteristic equation, so we start writing that the determinant of the equation must be zero:

$$\left\| \bar{\mathbf{K}} - \frac{\omega^2}{k/m} \bar{\mathbf{M}} \right\| = \left\| \bar{\mathbf{K}} - \Omega^2 \bar{\mathbf{M}} \right\| = 0,$$

with $\omega^2 = 1200 \left(\frac{\text{rad}}{\text{s}}\right)^2 \Omega^2$.

Expanding the determinant

$$\left\| \begin{array}{ccc} 1 - 2\Omega^2 & -1 & 0 \\ -1 & 3 - 3\Omega^2 & -2 \\ 0 & -2 & 5 - 4\Omega^2 \end{array} \right\| = 0$$

we have the following algebraic equation of 3rd order in Ω^2

$$24 \left(\Omega^6 - \frac{11}{4} \Omega^4 + \frac{15}{8} \Omega^2 - \frac{1}{4} \right) = 0.$$

Example: table of eigenvalues etc

Superposition

Giacomo Boffi

Eigenvector
Expansion

Uncoupled
Equations of
Motion

Undamped
Damped System
Truncated Sum
Elastic Forces

Example

Here are the adimensional roots Ω_i^2 , $i = 1, 2, 3$, the dimensional eigenvalues $\omega_i^2 = 1200 \frac{\text{rad}^2}{\text{s}^2} \Omega_i^2$ and all the derived dimensional quantities:

$\Omega_1^2 = 0.17573$	$\Omega_2^2 = 0.8033$	$\Omega_3^2 = 1.7710$
$\omega_1^2 = 210.88$	$\omega_2^2 = 963.96$	$\omega_3^2 = 2125.2$
$\omega_1 = 14.522$	$\omega_2 = 31.048$	$\omega_3 = 46.099$
$f_1 = 2.3112$	$f_2 = 4.9414$	$f_3 = 7.3370$
$T_1 = 0.43268$	$T_2 = 0.20237$	$T_3 = 0.1363$

Example: eigenvectors and modal matrices

Superposition

Giacomo Boffi

Eigenvector
Expansion

Uncoupled
Equations of
Motion

Undamped
Damped System
Truncated Sum
Elastic Forces

Example

With $\psi_{1j} = 1$, using the 2nd and 3rd equations,

$$\begin{bmatrix} (3 - 3\Omega_j^2) & -2\psi_{3j} \\ -2\psi_{2j} & +(5 - 4\Omega_j^2) \end{bmatrix} \begin{Bmatrix} \psi_{2j} \\ \psi_{3j} \end{Bmatrix} = \begin{Bmatrix} 1 \\ 0 \end{Bmatrix}$$

The above equations must be solved for $j = 1, 2, 3$. The solutions are finally collected in the eigenmatrix

$$\Psi = \begin{bmatrix} 1 & 1 & 1 \\ +0.648535272183 & -0.606599092464 & -2.54193617967 \\ +0.301849953585 & -0.678977475113 & +2.43962752148 \end{bmatrix}.$$

The Modal Matrices are

$$\mathbf{M}^* = \begin{bmatrix} 362.6 & 0 & 0 \\ 0 & 494.7 & 0 \\ 0 & 0 & 4519.1 \end{bmatrix} \times 10^3 \text{ kg},$$
$$\mathbf{K}^* = \begin{bmatrix} 76.50 & 0 & 0 \\ 0 & 477.0 & 0 \\ 0 & 0 & 9603.9 \end{bmatrix} \times 10^6 \frac{\text{N}}{\text{m}}$$

Example: initial conditions in modal coordinates

Superposition

Giacomo Boffi

Eigenvector
Expansion

Uncoupled
Equations of
Motion

Undamped
Damped System
Truncated Sum
Elastic Forces

Example

$$\underline{\mathbf{q}}_0 = (\mathbf{M}^*)^{-1} \Psi^T \mathbf{M} \begin{Bmatrix} 5 \\ 4 \\ 3 \end{Bmatrix} \text{ mm} = \begin{Bmatrix} +5.9027 \\ -1.0968 \\ +0.1941 \end{Bmatrix} \text{ mm},$$

$$\underline{\dot{\mathbf{q}}}_0 = (\mathbf{M}^*)^{-1} \Psi^T \mathbf{M} \begin{Bmatrix} 0 \\ 9 \\ 0 \end{Bmatrix} \frac{\text{mm}}{\text{s}} = \begin{Bmatrix} +4.8288 \\ -3.3101 \\ -1.5187 \end{Bmatrix} \frac{\text{mm}}{\text{s}}$$

Example: structural response

Superposition

Giacomo Boffi

Eigenvector
Expansion

Uncoupled
Equations of
Motion

Undamped
Damped System
Truncated Sum
Elastic Forces

Example

These are the displacements, in mm

$$\begin{aligned}x_1 &= +5.91 \cos(14.5t + .06) + 1.10 \cos(31.0t - 3.04) + 0.20 \cos(46.1t - 0.17) \\x_2 &= +3.83 \cos(14.5t + .06) - 0.67 \cos(31.0t - 3.04) - 0.50 \cos(46.1t - 0.17) \\x_3 &= +1.78 \cos(14.5t + .06) - 0.75 \cos(31.0t - 3.04) + 0.48 \cos(46.1t - 0.17)\end{aligned}$$

and these the elastic/inertial forces, in kN

$$\begin{aligned}x_1 &= +249. \cos(14.5t + .06) + 212. \cos(31.0t - 3.04) + 084. \cos(46.1t - 0.17) \\x_2 &= +243. \cos(14.5t + .06) - 193. \cos(31.0t - 3.04) - 319. \cos(46.1t - 0.17) \\x_3 &= +151. \cos(14.5t + .06) - 288. \cos(31.0t - 3.04) + 408. \cos(46.1t - 0.17)\end{aligned}$$

As expected, the contributions of the higher modes are more important for the forces, less important for the displacements.